

Table Specifications:

Model	YOQ-E250
Wiremesh Size (mm)	250
Wiremesh Thickness (mm / inch)	3.5-6.5
Refrigeration Capacity	1 ton
(Refrigerant Type)	5
(Refrigerant Temperature °C)	2-15
Weight (kg)	10.94
Dimensions (mm)	840 * 940 * 1780

Installation:

**Enrobing** is a process of embedding a wire mesh into a concrete surface. It is used to reinforce concrete and prevent cracking. The process involves applying a layer of wire mesh to the surface of the concrete before it is finished.

The following steps describe the installation process:

1. Preparation: Enrobing is performed on a clean, smooth concrete surface. The surface should be free of any debris, oil, or other contaminants.
2. Enrobing: Enrobing is performed by applying a layer of wire mesh to the surface of the concrete. The mesh is applied in a zigzag pattern, with the wires overlapping by approximately 25mm.
3. Enrobing: Enrobing is performed by applying a layer of wire mesh to the surface of the concrete. The mesh is applied in a zigzag pattern, with the wires overlapping by approximately 25mm.

The 250mm Enrobing is applied to the surface of the concrete. The mesh is applied in a zigzag pattern, with the wires overlapping by approximately 25mm.

The mesh is applied in a zigzag pattern, with the wires overlapping by approximately 25mm.

Omron is a brand of electrical components.

**& amp;** Installation:

1. Preparation: The surface should be clean and smooth. The mesh should be applied in a zigzag pattern, with the wires overlapping by approximately 25mm.
2. Enrobing: Enrobing is performed by applying a layer of wire mesh to the surface of the concrete. The mesh is applied in a zigzag pattern, with the wires overlapping by approximately 25mm.

Notes:

1. The mesh should be applied in a zigzag pattern, with the wires overlapping by approximately 25mm. The mesh should be applied in a zigzag pattern, with the wires overlapping by approximately 25mm.

2. The mesh should be applied in a zigzag pattern, with the wires overlapping by approximately 25mm. The mesh should be applied in a zigzag pattern, with the wires overlapping by approximately 25mm.

Notes:









□□□□□ □□□□□□□□:



□□□□□□:







□□□□□□□□:

**4 Certificates** 

**CERTIFICATES FOR QUALITY ASSURANCE**

<p><b>CE</b></p>  <p>Equipment variety complete, reasonable price !</p>	<p><b>CE</b></p> 	<p><b>Patent Certificate</b></p> 	<p><b>ISO</b></p>  <p>Excellent quality assurance, customer service !</p>	<p><b>ISO</b></p> 
--	--	--	---	---

□□□□□□ □□ □□□□:

